

Racing Beat Aluminum Flywheel Replacement Friction Plate

The kit comes supplied with all required bolts, washers, and lock nuts. Remove the used friction plate from the aluminum flywheel and clean the surface of the flywheel thoroughly.

Using the supplied hardware, install the friction plate. Securing the nuts using a cross-tightening sequence.

Torque the 3/16" lock nuts to 65 inch-pounds maximum.