

**1986-1992 RX-7 Front Sway Bar**

Part No. 14103

**INSTALLATION INSTRUCTIONS**

1. Raise the front of the car and support with jackstands. DO NOT work under a car which is supported only by a hand jack.
2. Remove the plastic undertray to expose the stock swaybar.
3. Disconnect the links from the swaybar, unbolt the support clips, and remove the sway bar.
4. Apply a small amount of the supplied grease to the inside of the pivot bushings. Use approximately 1/4 of the packet for each bushing. If required, additional grease packets (PN 14299) are available from Racing Beat. Install the urethane bearings and the new swaybar support clips on the Racing Beat sway bar.
5. Lift the swaybar into position and bolt the clips to the chassis. DO NOT fully tighten yet.
6. Insert the link bolts. Make sure the link bolts are on the OUTSIDE of the swaybar. Do not tighten these bolts yet.
7. Tighten the support clip bolts to 17 foot-pounds.
8. Reinstall the plastic tray.
9. Lower the car to the ground and roll it backward and forward several feet to settle the suspension.
10. Tighten the link bolts to 32 foot-pounds.

WE STRONGLY RECOMMEND RE-CHECKING THE TORQUE ON ALL COMPONENTS AFTER THE INITIAL CHECK DRIVE.