

I-67110

RX-8 Bumper Fairings PN 67110 Installation Instructions

- Estimated time for completion: 1 hr
- People required: 1

Before you start the installation process, please read through the following steps thoroughly.

Your Bumper Fairings may require final sanding and possibly the application of a small amount of plastic filler to fully surface-finish the piece prior to painting. Always check product for fitment on the vehicle before painting, drilling or cutting. Improper installation may void your warranty. Parts which have been modified, prepped or painted cannot be returned.

Fitting and Painting Preparation

- 1. Place the fairings on the car and confirm fitment. If required, fit the fairings to the car.
- 2. Remove the fairings and apply paint.

Installation

- 3. Apply a length of the automotive double-sided tape to each of the two mounting surfaces on the underside of each fairing as shown in Photo A.
- 4. Remove the adhesive backing and place the fairings onto place on the car.
- 5. Installation of the fairings are now complete.



Photo A