

## 1993-95 RX-7 Front Sway Bar Part No. 14107

### Installation Instructions

Raise the front of the car and support with jackstands. DO NOT work under a car which is supported only by a hand jack.

1. Remove the plastic undertray to expose the stock sway bar.
2. Disconnect the links from the sway bar, unbolt the sway bar brackets, and remove the sway bar.
3. Apply a small amount of the supplied grease to the inside of the pivot bushings. Use approximately 1/4 of the packet for each bushing. If required, additional grease packets (PN 14299) are available from Racing Beat. Install the urethane bearings and the new sway bar support clips on the Racing Beat sway bar.
4. Orient the bar so that, when the bar is laid on the ground, the threaded bar ends point slightly upwards above the plane of the floor.
5. Lift the sway bar into position and bolt the attachment brackets to the chassis with the supplied rectangular spacers between the brackets and the chassis. DO NOT fully tighten the bolts at this time.
6. Place a washer under the head of the link bolt and insert the bolt through the endlink, then into the end of the sway bar. Tighten to 30-34 ft/lbs.
7. Tighten the support bracket bolts to 14-19 ft/lbs.
8. Reinstall the plastic tray.
9. Lower the car to the ground and roll it backward and forward several feet to settle the suspension.