

## 1993-95 RX-7 Sway Bar Brace Kit

### INSTRUCTIONS

1. Raise the car and support the car with jack stands. Remove the plastic shroud which covers the front sway bar.
2. Remove the four (4) bolts that secure the sway bar brackets to the chassis. Remove the two (2) forward bolts on the power steering rack that will attach to the sway bar brace.
3. Position the sway bar brace between the sway bar and the chassis.
4. Insert the mounting bolts and loosely tighten.
5. Tighten the sway bar bracket bolts to 14-19 ft/lbs. Tighten the brace to power steering rack bolts to 27-38 ft/lbs.
6. Replace the plastic shroud and lower the car to the ground.