

## Front Lower Control Arm Brace

### Part No. 54008

### Installation Instructions

Note: Be sure that you have the correct Allen keys for the bolts before starting this installation. One 7/32" and one 3/8" Allen wrench are required for this installation.

1. Raise the car onto jack stands. Set the parking brake, and block wheels.
2. Drop nut plates in behind the lower "A" arm aft chassis mount with small holes positioned outboard.
3. Start all bolts and tighten lightly.
4. Torque large Allen bolts to 50 ft lbs and small Allen bolts to 30 ft lbs.
5. Lower car, remove wheel blocks.

