

INSTRUCTIONS FOR STREET AND RACE REAR PRESSURE REGULATORS

Part No. 11810, 11812

When installing either the street or race rear pressure regulator, it is necessary to shim the front cover pressure regulator with the two washers supplied to balance the increased pressure of the street or race rear pressure regulator.

The front cover pressure regulator is accessed by removing the oil pan. Remove the threaded cap on the front cover pressure regulator, install the washers between the cap and the spring, and re-install the cap.